

OpenEye[®]

2MP Outdoor IR IP Bullet Camera

User Manual



Camera

CM-722I

CM-722AI

CM-722VF

2MP IR IP Bullet Camera (CM-722 Series)

User Manual

Manual Edition 31051AC – JULY 2013

©2013, OPENEYE

All Rights Reserved.

No part of this documentation may be reproduced in any means, electronic or mechanical, for any purpose, except as expressed in the Software License Agreement. OpenEye shall not be liable for technical or editorial errors or omissions contained herein. The information in this document is subject to change without notice.

The information in this publication is provided “as is” without warranty of any kind. The entire risk arising out of the use of this information remains with recipient. In no event shall OPENEYE be liable for any direct, consequential, incidental, special, punitive, or other damages whatsoever (including without limitation, damages for loss of business profits, business interruption or loss of business information), even if OPENEYE has been advised of the possibility of such damages and whether in an action or contract or tort, including negligence.

This documentation is copyrighted. All other rights are reserved to OPENEYE. OPENEYE, and OpenEye, are registered trademarks of OPENEYE in the United States and elsewhere; Windows, and Windows XP Embedded are registered trademarks of Microsoft Corporation. All other brand and product names are trademarks or registered trademarks of the respective owners.

OPENEYE

Liberty Lake, WA • U.S.A.

Important Safeguards

1. **Read Instructions**
Read all of the safety and operating instructions before using the product.
2. **Retain Instructions**
Save these instructions for future reference.
3. **Attachments / Accessories**
Do not use attachments or accessories unless recommended by the appliance manufacturer as they may cause hazards, damage product and void warranty.
4. **Installation**
Do not place or mount this product in or on an unstable or improperly supported location. Improperly installed product may fall, causing serious injury to a child or adult, and damage to the product. Use only with a mounting device recommended by the manufacturer, or sold with the product. To insure proper mounting, follow the manufacturer's instructions and use only mounting accessories recommended by manufacturer.
5. **Power source**
This product should be operated only from the type of power source indicated on the marking label.

Precautions

Operating

- Before using, make sure power supply and others are properly connected.
- While operating, if any abnormal condition or malfunction is observed, stop using the camera immediately and then contact your local dealer.

Handling

- Do not disassemble or tamper with parts inside the camera.
- Do not drop or subject the camera to shock and vibration as this can damage camera.
- Do not block the cooling holes on the bracket. This camera has a cooling fan inside the housing. Blocking the cooling holes will cause heat to build up and cause malfunction.
- Care must be taken when you clean the clear dome cover. Scratches and dust will ruin the image quality of your camera. Do not use strong or abrasive detergents when cleaning the camera body. Use a dry cloth to clean the camera when it is dirty. In case the dirt is hard to remove, use a mild detergent and wipe the camera gently.

Installation and Storage

- Install electricity wiring carefully. Please note that input electricity to the unit is at tolerance of DC 12V/AC 24V \pm 10%. The camera is capable of surge protection; ensure AC power model unit is grounded appropriately against damage by heavy current or electric shock.
- Do not install the camera in areas of extreme temperatures in excess of the allowable range. (-40°F ~ 122°F / -40°C ~ 50°C)
- Avoid installing in humid or dusty places. The relative humidity must be below 90%.
- Avoid installing in places where radiation is present.
- Avoid installing in places where there are strong magnetic fields and electric signals.
- Avoid installing in places where the camera would be subject to strong vibrations.
- Never face the camera toward the sun. Do not aim at bright objects. Whether the camera is in use or not, never aim it at the sun or other extremely bright objects. Otherwise the camera may be smeared and damaged.

Regulation



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste in accordance with Directive 2002/96/EC. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By proper waste handling of this product you ensure that it has no negative consequences for the environment and human health, which could otherwise be caused if this product is thrown into the garbage bin. The recycling of materials will help to conserve natural resources.



For more details information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Compliance is evidenced by written declaration from our suppliers, assuring that any potential trace contamination levels of restricted substances are below the maximum level set by EU Directive 2002/95/EC, or are exempted due to their application.

Warning

DANGEROUS HIGH VOLTAGES ARE PRESENT INSIDE THE ENCLOSURE.
DO NOT OPEN THE CABINET.
REFER SERVICING TO QUALIFIED PERSONNEL ONLY.

Caution




TABLE OF CONTENTS

Introduction	10
Overview	10
Product Features	10
Getting Started	11
Box Contents	11
Camera Overview	12
Dimensions	12
Connections	13
Micro SD Card Slot and Reset Button	14
Installing the Desiccant	16
Installation	17
Power and Ethernet Connection	17
Power Connection	17
Ethernet Cable Connection	17
Ceiling Installation	18
Lens Adjustment	19
Locate Camera	20
OpenEye Network Camera manager	20
Installation	20
Starting Network Camera Manager	20
Device Addressing	21
Finding Network Devices	21
Setup & Configuration	22
Connecting to the Camera	22
Resetting the Camera	22
Administrator/User Privileges	22
Connecting a Stream	23
Connecting Over the Internet	24
Viewer Software	25
Viewer Tabs	25
Home	26
CM-722I and CM-722VF Models	26
CM-722AI	27

System	28
System	28
Security	29
Admin Password	29
Add User	30
Delete user	30
Edit user	30
Network	31
Get IP address automatically (DHCP)	31
Use fixed IP address	32
DDNS	33
Mail	34
FTP	35
Application	36
Motion Detection	38
Storage Management	42
Recording	43
Snapshot	44
Information	45
System Log	45
View User Information	46
View User Privilege	46
Parameter List	47
Software Upgrade	48
Upgrading the Camera Viewer Software	48
Maintenance	50
Video and Audio Streaming Settings	51
Video Format	51
Text Overly Settings	51
Video Rotate Type	52
Video Compression	53
Video OCX Protocol	54
Multicast Mode	54
Frame Rate Control	55
Video Mask	56
Audio	57
Transmission Mode	57
Server Gain Setting	58

Bit Rate	58
Camera	59
Exposure	59
White Balance	60
Backlight Setting	60
Brightness	60
Sharpness	60
Contrast	61
Saturation	61
Digital Zoom	61
IR Function	61
TV System	61
Logout	61
Specifications	62
Camera Specifications	62
IR Specifications	63
IP Specifications	63
Appendix A	64
Set Up Internet Security	64
Setting Internet Security Level to Default	64
Adjusting ActiveX Controls and Plug-ins	65

INTRODUCTION

OVERVIEW

The OpenEye CM-722 series is a collection of 2MP outdoor IP bullet cameras built to provide superior video quality. All CM-722 cameras utilize MJPEG or H.264 compression to provide video at resolutions up to 1080p (2MP) and are capable of dual and quad streaming at 720p (1MP). Each camera in the CM-722 series is equipped with 23 IR LEDs and a mechanical IR cut filter for true day/night operation, allowing the camera to record high-resolution images at 0 Lux.

The CM-722I is equipped with all the standard features of the CM-722 line, while the CM-722AI includes a motorized lens and the CM-722VF includes a varifocal lens.

The CM-722 series is designed to operate in extreme conditions in a tamper-resistant housing. It is equipped with an integrated heater, allowing operation in temperatures as low as -40°F (-40°C). CM-722 cameras can be powered via 24vAC, 12vDC, or a PoE switch. 24vAC power is required to operate the on-board heater.









Product Features

- ONVIF™ compliant
- H.264 / MJPEG quad streaming
- 2MP resolution (1080p HD)
- IP66 weatherproof rating
- True Day/Night
- On-board heater
- 23 IR LEDs

GETTING STARTED

BOX CONTENTS



Before proceeding, please check that the box contains the items listed here. If any item is missing or has defects, DO NOT install or operate the product and contact your dealer for assistance.

		
CM-722 Series Camera (Cable included)		Power Terminal Block
		
Self Tapping Screws	Plastic Anchors	
		
Quick Start Guide	Desiccant Bag	CD

CAMERA OVERVIEW


Before installing or connecting the camera, please refer to this section, including an overview of the all-in-one cable for reference.

Dimensions



- Length – 10.5 inches (84 mm)
- Width – 2.75 inches (69.9 mm)
- Height – 3.25 inches (82.55 mm)

Connections




No.	Item	Pin	Definition		Remarks
1	Network (with PoE)	-	RJ-45 connector w/ LED		
2	Power (3-pin Terminal Block)	1	AC 24V-1	DC (-)	Power connection
		2	GND	Reserved	
		3	AC 24V-2	DC (+)	
3	Alarm I/O	1	ALM_DI-		Alarm connection
		2	ALM_DI+		
		3	ALM_DO-		
		4	ALM_DO+		
4	Audio I/O	Pink	Line In/Mic In		Two-way audio transmission
		Green	Line Out		
5	BNC	-	Video out		


Micro SD Card Slot and Reset Button

Use these photos to reach the Micro SD card slot, reboot button, and factory default button.


1. Unscrew the camera housing to remove front cover.




2. Micro SD card slot



3. Factory default button




4. Reboot Button




Installing the Desiccant

To prevent condensation on the glass cover of the CM-722, OpenEye recommends placing the desiccant in the camera before installation and replacing the desiccant each time the front cover is opened.

1. Unfasten the screw on the camera housing and remove the front cover



2. Carefully tear open the aluminum desiccant envelope and remove the desiccant.
3. Remove paper backing from the adhesive strip on the desiccant packet.
4. Place the desiccant firmly in the position indicated in here.



5. Reinstall the front cover and fasten the screw.

INSTALLATION

POWER AND ETHERNET CONNECTION

Read the installation instructions before installing and connecting the IP camera.

Power Connection

Make sure that the camera's power cable is correctly and firmly connected..

Note OpenEye recommends against using more than one power source at a time. Do not use a PoE power source when providing the camera with 12vDC or 24vAC power.

Make sure the camera's power cable is correctly and firmly connected. If using Power over Ethernet (PoE), make sure Power Sourcing Equipment (PSE) is in use in the network.

Ethernet Cable Connection

OpenEye recommends using Category 5 Ethernet cable to connect the camera to your network. For the best transmission quality, the cable length should not exceed 328 feet (100 meters). Connect a network cable to the camera using the RJ45 input and connect the other end of the cable to your network switch or recorder.


Note If you are connecting the camera directly to a recorder, a crossover cable is necessary for most configurations.

Check the status of the network connection by looking at the link indicator and activity indicator LEDs. If the LEDs are not lit check your network connection. The green link LED indicates a network connection and the orange activity LED flashes to indicate network activity.


CEILING INSTALLATION

The IR Bullet IP Camera can be installed directly on a wall or ceiling provided it has enough strength to support the camera.

1. Remove the IR Bullet IP Camera from packaging
2. Connect power, Ethernet, Alarm and audio wires from ceiling or wall to the corresponding connectors of the camera's all-in-one cable.
3. Fix the camera's bracket on the ceiling or wall with the three supplied self-tapping screws.



4. Use the supplied inner hex wrench and a Phillips screwdriver to loosen the hex bolt on the side of the bracket mount and the camera housing to adjust the position of the camera.



Note CM-722 cameras are equipped with a seal inside the housing to prevent moisture from entering. If you have any concerns about moisture entering the housing or wall through the cable egress, OpenEye recommends sealing the opening at the wall and at the base of the camera with silicone caulking.

LENS ADJUSTMENT

1. Unscrew the camera housing to remove front housing.



2. Connect the power, audio, and alarm wires to their corresponding connectors. (Refer to the pin definition table.)
3. Access the camera browser in order to view images.
4. Adjust the zoom/focus ring screw on the lens to set the desired zoom and focal length.
5. Replace front housing and tighten screw.

LOCATE CAMERA

OPENEYE NETWORK CAMERA MANAGER

Use the included Network Camera Manager software to easily find your network cameras for initial setup. The OpenEye IP Finder software is included on the CD with all OpenEye IP devices.

Installation

You can install Network Camera Manager on any personal computer (PC) or laptop using the software CD included with your OpenEye IP camera or by downloading the program from openeye.net.

Note Network Camera Manager will only work on PCs or laptops that use a Windows operating system. It is compatible with Windows XP, Vista, 7, and 8.

Starting Network Camera Manager

After installing the program on your PC or laptop, open the program to begin configuring your cameras.

To access Network Camera Manager on an OpenEye recorder, you must operate the recorder in Windows Mode.

1. In the Live Screen, click **Exit**.
2. Click **Restart in Windows Mode**.
3. Click **OK**.
4. Double-click **Network Camera Manager**.

Device Addressing

The functions on the Device Addressing tab allow you to find, configure, and view network cameras.

Finding Network Devices

5. Click **Find Devices** on the **Device Addressing** tab.
6. To narrow your search by **Camera Model**, **Project**, or **Camera Name**, select your desired criteria from the appropriate lists.

OpenEye NETWORK CAMERA MANAGER

File Help

Camera login: Username: Admin Password: 1234 Camera Model: Project: Camera Name:

Find Devices

Model	Project	Name	IP Address	MAC	Netmask	Gateway	Port	DNS
CM-611	OpenEye	Training R...	10.88.88.153	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Training R...	10.88.88.151	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Security Ca...	10.47.47.151	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Training R...	10.88.88.159	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Training R...	10.88.88.150	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Training R...	10.88.88.162	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Training R...	10.88.88.158	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Support -6...	10.89.90.3	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	Training R...	10.88.88.160	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19
CM-611	OpenEye	CM-611	10.10.10.20	00:D0:89:0...	255.0.0.0	10.0.0.1	80	10.0.0.19

73 Devices discovered

Auto IP Network Addressing

Beginning IP: Network Mask: Gateway: DNS:

Host Configuration

You can quickly change the configuration of the selected devices listed above.

Static DHCP

Apply the network updates listed on this page to all selected cameras. Apply Settings

Undo network configuration changes. Undo Changes

SETUP & CONFIGURATION

CONNECTING TO THE CAMERA

1. Locate the camera using the Network Camera Manager.
2. Double-click the camera to open the Viewer software in your web browser.
3. Log in to the camera with the appropriate **User Name** and **Password**.

Note The default User name is Admin and the default Password is 1234. The username and password are case sensitive. OpenEye recommends you change the Admin password for security reasons.

Resetting the Camera

If it is necessary to reset the camera to the factory default settings, hold down the Reset button (see *Connections*) for 30 seconds. This will return all settings, including network setup, to the factory default. The IP address of the camera will return to 192.168.0.250.

Administrator/User Privileges

The Administrator account has the authority to configure the IP camera and authorize users' access to the camera. The User accounts have access to the camera with limited authority.

Connecting a Stream

OpenEye IP cameras are optimized for use with OpenEye recorders, but you can also connect to your OpenEye IP cameras using third party software like VLC media player (<http://www.videolan.org>).

To connect the camera you may need to provide the stream URL. All OpenEye IP cameras are capable of delivering two RTSP streams, as well as streaming MJPEG over HTTP. The stream URLs are listed below.


rtsp://<ip address>/mjpeg

rtsp://<ip address>/mpeg4

rtsp://<ipaddress>/h264

http://<ipaddress>:8008

The MJPEG over HTTP stream is identified by a port number. The default port is 8008; this port can be configured in the cameras **Network** page:



The screenshot shows the OpenEye web interface with the 'System' tab selected. The left sidebar contains a menu with options: System, Security, Network, DDNS, Mail, FTP, HTTP, Application, Motion detection, Storage management, Recording, File location, Iris adjustment, View log file, View user information, View parameters, Factory default, Software version, Software upgrade, and Maintenance. The main content area is titled 'Network' and has a 'General' section. In the 'General' section, the 'Use fixed IP address' option is selected. The IP address is 10.4.5.86, Subnet mask is 255.0.0.0, Default gateway is 10.0.0.50, Primary DNS is 10.0.0.19, and Secondary DNS is 0.0.0.0. The 'Use PPPoE' option is also present. The 'Advanced' section shows the Web Server port as 80, RTSP port as 554, and MJPEG over HTTP port as 8008. A red arrow points to the MJPEG over HTTP port field. The 'UPnP Setting' section shows 'Enable UPnP' checked and 'Enable UPnP port forwarding' unchecked. The 'Friendly name' is CM-730.

Section	Option	Value
General	Get IP address automatically	<input type="radio"/>
	Use fixed IP address	<input checked="" type="radio"/>
	IP address	10.4.5.86
	Subnet mask	255.0.0.0
	Default gateway	10.0.0.50
	Primary DNS	10.0.0.19
General	Secondary DNS	0.0.0.0
	Use PPPoE	<input type="radio"/>
UPnP Setting	User name	
	Password	
Advanced	Web Server port	80
	RTSP port	554
	MJPEG over HTTP port	8008
UPnP Setting	Enable UPnP	<input checked="" type="checkbox"/>
	Enable UPnP port forwarding	<input type="checkbox"/>
UPnP Setting	Friendly name	CM-730

Connecting Over the Internet

There are some challenges with connecting to OpenEye IP cameras over WAN (internet) connections because the camera streams video over RTSP. RTSP is an excellent protocol for media and is now used on many IP cameras (including OpenEye) as the default streaming option.

However, RTSP is not suitable for transmission between two locations that are behind different routers. In this case, the client (for example, the OpenEye HVR or NVR server software) connects to the camera, then requests a stream. The camera uses that connection to return a stream, but since the connection originated on the client side and has now switched to the camera (remote) side, the router does not have any way to determine where the traffic should be routed, so no video appears at the recorder.

There are three solutions to this:

1. Connect modems on both sides directly to the recorder and camera. If there is no router, no network address translation is needed.
2. Use routers with VPN support and set up a small VPN. Once this is done, the traffic will be treated as though it were all on the local network.
3. **(Best solution)** – Use routers with **connection tracking**. This is quite easy; VOIP also uses RTSP and faces the same challenges. If a router is marketed as having “VOIP Support”, it will have the necessary connection tracking capability to allow any type of RTSP communication (not just VOIP).


With proper planning and the correct equipment, RTSP cameras CAN stream over the WAN to a recording device for minimal additional cost and labor.

Please contact OpenEye support if you require any additional information on these topics.

VIEWER SOFTWARE

To access the setup menu, you need to install the viewer software on your PC or recorder. The viewer software will install automatically the first time you connect to the camera. If your internet browser doesn't install the viewer software, check the security settings or ActiveX controls and plug-in settings. For additional information on adjusting the settings of your Internet Explorer browser contact your system administrator or refer to openeye.net. If your internet browser asks for permission to install the ActiveX control, you must allow the ActiveX control to continue the installation.

The first time you connect to a camera, the browser will ask for permission to install the ActiveX Control necessary to display the camera video. Right-click the information bar and click **Install ActiveX Control** to allow the installation. If you experience issues, see Appendix A: Set Up Internet Security



Viewer Tabs

Home – Monitor live video.

System – Set the host name, system time, root password, and network related settings.
(Admin access only)

Streaming – Modify the video resolution and select the audio compression type.

Camera – Adjust the camera parameters including Exposure, White Balance, Brightness, Sharpness, Contrast, and Digital Zoom.


Logout – Change user.

Home


CM-722I and CM-722VF Models

Screen Size Adjustment – Click the screen size buttons to adjust image display size x1/2 and full screen.

Digital Zoom Control – In full screen mode, right-click to activate digital zoom and use the scroll wheel to zoom in/out.



Talk – Talk allows the local site to talk to the remote site. This function is only available to Users who have been granted this privilege by the Administrator.

Snapshot – Click the  button, and a JPEG snapshot will automatically be saved in the appointed place. The default location is: C:\.


Note If you are using Windows Vista or 7, you will need to change the Snapshot location. Windows UAC does not allow internet programs to write directly to C:\ for security reasons.

CM-722AI

The CM-722AI is equipped with a motorized autofocus lens that makes installation quick and easy.

There are six main buttons that are used when setting up the CM-722AI:

- Zoom Tele
- Zoom Wide
- Focus Near
- Focus Far
- Push AF
- Reset



Use these buttons to control the camera's zoom and focus. Click **Push AF** to automatically focus the camera. The camera will keep this focus setting until it receives another command.

Once the CM-716A is installed in the preferred location, use the **Zoom** and **Focus** buttons to set the camera's field of view and then click the **Push AF** button to focus the camera. To return the lens to the default setting, click **Reset**.

System

Note The System tab is only accessible by the Administrator.

System

OpenEye Home System Streaming Camera Logout

System

Host Name : CM-730

Time zone : GMT+00:00 Gambia, Liberia, Morocco, England

☐ Enable daylight saving time

time offset: 01:00:00

Start date: Jan 1st Sun Start time: 00:00:00

End date: Jan 1st Sun End time: 00:00:00

☒ Sync with computer time

PC date: 2010/10/05 [yyyy/mm/dd]

PC time: 15:53:50 [hh:mm:ss]

☐ Manual

Date: 2007/01/01 [yyyy/mm/dd]

Time: 00:00:00 [hh:mm:ss]

☐ Sync with NTP server

NTP server: 0.0.0.0 [host name or IP address]

Update interval: Every hour

Save

Host Name – The Host Name is used to identify the camera on your system. If camera-based Motion Detection is enabled and is set to send alarm message by Mail/FTP, the host name entered here will display in the alarm message.

Time Zone – Select your time zone.

Sync With Computer Time – Select to synchronize the camera date and time with the connected PC or recorder.

Manual – Set video date and time manually.

Sync with NTP server – Network Time Protocol (NTP) is an alternate way to set your camera's clock by synchronizing with an NTP server. Specify the server you wish to synchronize in the **NTP Server** box. Then select an **Update Interval**. For more information about NTP, visit www.ntp.org.

Security

OpenEye

HomeSystemStreamingCameraLogout

System

Security

Network

DDNS

Mail

FTP

Application

Motion detection

Storage management

Recording

File location

Iris adjustment

View log file

View user information

View parameters

Factory default

Software version

Software upgrade

Maintenance

Security

Admin Password

Admin password

Confirm password

Save

Add User

User name

User password

☒ I/O access

☐ Camera control

☐ Talk

☐ Listen

Add

Manage User

User name

-- no user --

Delete

Edit

Admin Password

To change the administrator password, type a new password in the Admin Password box and confirm below.

Note The maximum length of the password is 14 characters. The following characters are valid: A-Z, a-z, 0-9, !#\$%&'-.@^_~.

Add User

The user name and passwords are limited to 16 characters. The maximum number of user accounts is 20.

4. Type the new User name and Password.
5. Select the appropriate check boxes to give the user Camera Control, Talk and Listen permissions.

I/O access – Basic functions that enable users to view video when accessing to the camera.

Camera control – Allows the User to change camera parameters on the Camera tab.

Talk/Listen – Talk and Listen functions allow the user at the local site (DVR) to communicate with, the administrator at the remote site.

6. Click **Add**.

Delete user


1. Select the user name on the **User Name** list
2. Click **Delete** to remove the user.

Edit user

1. Select the user name on the **User Name** list
2. Click **Edit** to edit the user password and permissions.
3. Type a new password or the existing password in the User password box

Note You must type a password in the User password box to make any changes to an account.

Note For security reasons every time the user properties are opened, the access check boxes are automatically cleared. Make sure you select any user access options each time you edit the user properties.



The screenshot shows a web browser window with the address bar displaying 'http://192.168.7.234/lang1/server_editaccount.html - Micr...'. The form contains the following elements:

- User name**: A text input field containing '[User]'.
- User password**: A text input field with masked characters (dots).
- Permissions**: Four checkboxes arranged in two columns:
 - ☒ I/O access
 - ☐ Camera control
 - ☐ Talk
 - ☐ Listen
- Buttons**: Two buttons at the bottom, 'Save' and 'Close'.

Network

OpenEye

HomeSystemStreamingCameraLogout

SystemSecurityNetworkDDNSMailFTPApplicationMotion detectionStorage managementRecordingFile locationIris adjustmentView log fileView user informationView parametersFactory defaultSoftware versionSoftware upgradeMaintenance

Network

General

☐ Get IP address automatically

☒ Use fixed IP address

IP address

10.4.5.101

Subnet mask

255.0.0.0

Default gateway

10.0.0.50

Primary DNS

10.0.0.19

Secondary DNS

0.0.0.0

☐ Use PPPoE

User name

Password

Save

Advanced

Web Server port

80

RTSP port

554

MJPEG over HTTP port

8008

Save

UPnP Setting

☒ Enable UPnP

☐ Enable UPnP port forwarding

Friendly name

CM-730

Save

You can choose to use a fixed IP address or a dynamic IP address (assigned by a DHCP server or router) for the camera.

Get IP address automatically (DHCP)

The camera comes preconfigured with a fixed IP address.

Note Every network device has a unique Media Access Control (MAC) address that can be used for identification. The MAC address is located on the bottom of each camera, and on the box label (the OpenEye IP Finder also displays the MAC address for identification). Record your camera's MAC address for identification in the future.

Use fixed IP address

To set up a new static IP address:

1. Select the Use fixed IP address option.
2. Type a new IP address in the **IP address** box.
3. Type a new address in the Default Gateway box.
4. Click **Save** to confirm the new setting.

When using static IP address to log in to the IP Camera, you can access it either through OpenEye IP Finder software or type the IP address directly in the address bar of your internet browser.

General

- **IP address** – The IP Address is necessary for network identification.
- **Subnet mask** – Used to determine if the destination is in the same subnet. The default value is 255.255.255.0.
- **Default gateway** – Used to forward frames to destinations on different subnets or for internet access.
- **Primary DNS** – The primary domain name server that translates hostnames into IP addresses.
- **Secondary DNS** – A secondary domain name server that backups the primary DNS.
- **Web Server port** – Defines the port that Internet Explorer uses to connect over the web and view video. If this port is changed then the new port must be defined when attempting to web connect (ex: if your camera's IP address is 192.168.0.100 and you change the web port to 8001, then you must type http://192.168.0.100:8001 in your browser).

Advanced

- **RTSP port** – The default RTSP port is 554; setting range: 1024 ~65535.
- **MJPEG over HTTP port** – The default HTTP Port is 8008; setting range: 1024 ~65535.

Note The MJPEG over HTTP port cannot be the same as the web server port.

Use PPPoE

For PPPoE users, enter the PPPoE username and password into the fields and click **Save** to complete the setting.

IPv6 Address Configuration

With IPv6 support, users can use the corresponding IPv6 address for browsing. Enable IPv6 by checking the box, then click **Save** to complete the setting.

DDNS

DDNS (Dynamic Domain Name Service) is a service that allows a connection to an IP address using a hostname (URL) address instead of a numeric IP address. Most Internet Service Providers use Dynamic IP Addressing that frequently changes the public IP address of your internet connection. This means that when connecting to the camera over the internet, you need to know if your IP address has changed. DDNS automatically redirects traffic to your current IP address when using the hostname address.

OpenEye Home System Streaming Camera Logout

System
Security
Network
DDNS
Mail
FTP
Application
Motion detection
Storage management
Recording
File location
Iris adjustment
View log file
View user information
View parameters
Factory default
Software version
Software upgrade
Maintenance

DDNS

Dynamic DNS
Use Dynamic DNS If You Want To Use Your DDNS Account.

☐ Enable DDNS

Provider: DynDNS.org(Dynamic)

Host name:

Username/E-mail:

Password/Key:

Save

- **Enable DDNS** – Select the check box to enable DDNS.
- **Provider** – Select a DDNS host from the Provider list.
- **Host name** – Type the registered domain name in the field.
- **Username/E-mail** – Type the username or e-mail required by the DDNS provider for authentication.
- **Password/Key** – Type the password or key required by the DDNS provider for authentication.

Mail

The camera can send an e-mail via Simple Mail Transfer Protocol (SMTP) when motion is detected or when the sensor input is activated. SMTP is a protocol for sending e-mail messages between servers. SMTP is a relatively simple, text-based protocol, where one or more recipients of a message are specified and the message text is transferred. The configuration page is shown as follows:

OpenEye Home System Streaming Camera Logout

System
Security
Network
DDNS
Mail
FTP
Application
Motion detection
Storage management
Recording
File location
Iris adjustment
View log file
View user information
View parameters
Factory default
Software version
Software upgrade
Maintenance

Mail
SMTP

1st SMTP (mail) server

1st SMTP (mail) server port

1st SMTP account name

1st SMTP password

1st recipient email address

2nd SMTP (mail) server

2nd SMTP (mail) server port

2nd SMTP account name

2nd SMTP password

2nd recipient email address

Sender email address

Save

Two sets of SMTP accounts can be configured. Each set includes SMTP Server, Account Name, Password and E-mail Address settings. For SMTP server, contact your network service provider for more specific information.

FTP

The camera can send alarm message to a specific File Transfer Protocol (FTP) site when motion is detected or when the sensor input is activated. You can assign alarm message to up to two FTP sites.

OpenEye Home System Streaming Camera Logout

System
Security
Network
DNS
Mail
FTP
Application
Motion detection
Storage management
Recording
File location
Iris adjustment
View log file
View user information
View parameters
Factory default
Software version
Software upgrade
Maintenance

FTP

Built-in FTP server port 21

1st FTP server

1st FTP server port 21

1st FTP user name

1st FTP password

1st FTP remote folder

☐ 1st FTP passive mode

2nd FTP server

2nd FTP server port 21

2nd FTP user name

2nd FTP password

2nd FTP remote folder

☐ 2nd FTP passive mode

Save

1. Enter the FTP details, which include server, server port, user name, password and remote folder, in the appropriate boxes.
2. Click **Save** when finished.

Application

The CM-722 is equipped with one alarm input and one relay output to connect to an alarm system to catch event images. Refer to **Camera Overview > Connections** to connect alarm devices to the IP Camera if needed.

OpenEye Home System Streaming Camera Logout

System
Security
Network
DNS
Mail
FTP
Application
Motion detection
Storage management
Recording
File location
Iris adjustment
View log file
View user information
View parameters
Factory default
Software version
Software upgrade
Maintenance

Application

Alarm Switch
☐ Off ☒ On

Alarm Type
☐ Normal close ☒ Normal open

Alarm Output
☒ Output high ☐ Output low

Triggered Action

<input checked="" type="checkbox"/> Enable alarm output	<input type="checkbox"/> Record stream to sd card
<input type="checkbox"/> Send message by FTP	<input type="checkbox"/> Send message by E-Mail
<input checked="" type="checkbox"/> Upload image by FTP	<input checked="" type="checkbox"/> Upload image by E-Mail
FTP address: FTP1	E-Mail address: E-Mail 1
Pre-trigger buffer: 5 frames	Pre-trigger buffer: 5 frames
Post-trigger buffer: 5 frames	Post-trigger buffer: 5 frames
<input type="checkbox"/> Continue image upload	<input type="checkbox"/> Continue image upload
<input checked="" type="radio"/> Upload for 1 sec	<input checked="" type="radio"/> Upload for 1 sec
<input type="radio"/> Upload during the trigger active	<input type="radio"/> Upload during the trigger active
Image frequency: Max. fps	Image frequency: Max. fps

File Name

File name: image.jpg

☒ Add date/time suffix

☐ Add sequence number suffix (no maximum value)

☐ Add sequence number suffix up to 0 and then start over

☐ Overwrite

Save

Alarm Switch – Enable or disable the alarm function.

Alarm Type – Select an alarm type, “Normal close” or “Normal open,” that corresponds with the alarm application.

Alarm Output – Define alarm output signal “high” or “low” as the normal alarm output status according to the current alarm application.

Triggered Action – Specify alarm actions that will take place when the alarm is triggered.

- **Enable Alarm Output** – Select to enable relay output on alarm.
- **IR Cut Filter** – Select the item and the camera's IR cut filter (ICR) will be removed or blocked when an alarm is triggered. The IR function cannot be set to auto mode if the triggered action is enabled.
- **Send Alarm Message by FTP/E-Mail** – Select to send an alarm message to a configured FTP and/or E-Mail address when an alarm is triggered. When sending to email, the alarm notification is text only. When sending to FTP, the alarm notification will upload a text file to the FTP location.

- **Upload Image by FTP** – Select to assign an FTP site. When the alarm is triggered, event images will be uploaded to the configured FTP site at the rate of one jpeg image per second.
- **Record Stream to SD Card** – Select the item and the alarm-triggered recording will be saved to your micro SD card. The pre-trigger buffer recording option allows users to check what happened to trigger the alarm. The pre-trigger buffer time range is from 1 to 3 seconds. Select **Upload for ___ Sec** to set the recording duration after the alarm is triggered. Select **Upload During Trigger Active** to record until the alarm is off. Local recording needs to be activated in order for this function to be implemented.
- **Upload Image by E-Mail** – Select to assign an e-mail address. When the alarm is triggered, event images will be sent to the configured e-mail address.
- **Send HTTP notification** – Select this item, select the destination HTTP address, and specify the parameters for event notifications when an alarm is triggered.

Note Make sure SMTP or FTP configuration has been completed. See the Mail and FTP section of this manual for further details.

File Name – Enter a file name in the box, ex. image.jpg. The uploaded image's file name format can be set in this section. Please select the one that meets your requirements.

- **Add date/time suffix**
File name: imageYYMMDD_HHNNSS_XX.jpg
Y: Year, M: Month, D: Day
H: Hour, N: Minute, S: Second
X: Sequence Number
- **Add sequence number suffix (no maximum value)**
File name: imageXXXXXXX.jpg
X: Sequence Number
- **Add sequence number suffix (limited value)**
File Name: imageXX.jpg
X: Sequence Number

The file name suffix will end with the value entered in this box. For example, if the setting is up to "10," the file name will start from 00, end at 10, and then start all over again.

Overwrite – The original image on the FTP site will be overwritten by the new uploaded file with a static filename.

Motion Detection

Motion Detection allows the camera to detect motion and trigger alarms when motion in the detected area exceeds the determined sensitivity threshold value.

OpenEye
[Home](#)
[System](#)
[Streaming](#)
[Camera](#)
[Logout](#)

[System](#)
[Security](#)
[Network](#)
[DDNS](#)
[Mail](#)
[FTP](#)
[Application](#)
[**Motion detection**](#)
[Storage management](#)
[Recording](#)
[File location](#)
[Iris adjustment](#)
[View log file](#)
[View user information](#)
[View parameters](#)
[Factory default](#)
[Software version](#)
[Software upgrade](#)
[Maintenance](#)

Motion Detection

Motion Detection

☒ Off ☐ On

Motion Detection Setting

Sampling pixel interval [1-10]	<input type="text" value="1"/>
Detection level [1-100]	<input type="text" value="10"/>
Sensitivity level [1-100]	<input type="text" value="80"/>
Time interval(sec) [0-7200]	<input type="text" value="10"/>

Triggered Action

☐ Enable alarm output


☐ Record stream to sd card

☐ Send alarm message by FTP

☐ Upload image by FTP

File Name :

☒ Add date/time suffix
☐ Add sequence number suffix (no maximum value)
☐ Add sequence number suffix up to and then start over
☐ Overwrite



Motion Detection Windows


☐ Send alarm message by E-mail
☐ Upload image by E-Mail

In the Motion Detection page, there is a motion detection window (red box) displayed on the Live View Pane. The Motion Detection window defines the motion detection area. To change the size of the Motion Detection window, drag the edge of the frame to resize.


You can add up to 10 motion detection windows.

- Click **Add** under the Live View Pane to add a Motion Detection window.
- To delete a Motion Detection window, use the mouse to select the frame and click **delete**.

When motion detection is activated, the **Motion** pop-up window will open.



When motion is detected, the signals will be displayed on the Motion window as shown below.



Motion Detection

Turn motion detection on or off. The default setting is Off.

Motion Detection Setting

- **Sampling pixel interval [1-10]** – Default value is 10, which means system will take one sampling pixel for every 10 pixels.
- **Detection level [1-100]** – Default detection level is 10. This item sets the detection level for each sampling pixel; the smaller the value, the more sensitive it is.
- **Sensitivity level [1-100]** – The default sensitivity level is 80, which means if 20% or more sampling pixels are detected as changed, the system will detect motion. The bigger the value, the more sensitive it is. As the sensitivity value is increased, the red horizontal line in the motion indication window will be lowered accordingly.
- **Time interval (sec) [0-7200]** – The default interval is 10. The value is the interval between each detected motion event.

Triggered Action

You can specify which actions the camera should take when motion is detected.

- **Enable Alarm Output** – This will activate the camera's alarm output.
- **Record Stream to SD Card** – Select this item and the motion detection recording will be stored in the Micro SD/SDHC card when motion is detected. The pre-trigger buffer time range is 1-3 seconds. Select **Upload for ___ Sec** to set the recording duration after motion is triggered. Select **Upload During the Trigger Active** to record until the alarm is off.
- **Send Alarm Message by FTP/E-Mail** – Select to send an alarm message to a configured FTP server and/or e-mail address when motion is detected. When sent to e-mail, the alarm notification is text only. When sending to FTP, the alarm notification will upload a text file to the FTP location.
- **Upload Image by FTP** – Select to assign an FTP site and configure various parameters as shown in the figure below. When motion is detected, event images will be uploaded to the appointed FTP site.
- **Upload Image by E-Mail** – Select to assign an e-mail address and configure various parameters as shown in the figure below. When motion is detected, event images will be sent to the appointed e-mail address.

☒ Upload Image by E-Mail

E-Mail address E-Mail 1 ▼

Pre-trigger buffer 5 frames ▼

Post-trigger buffer 5 frames ▼

☐ Continue image upload

☒ Upload for 1 sec

☐ Upload during the trigger active

Image frequency Max. ▼ fps

Note Make sure SMTP or FTP configuration has been completed. See the Mail and FTP sections for more information.

- **Send HTTP Notification** – Check this item, select the destination HTTP address, and specify the parameters for event notifications by motion detection. When an alarm is triggered, the notification can be sent to the specified HTTP server.

File Name – Enter a file name in the box, ex. image.jpg. The uploaded image's file name format can be set in this section. Please select the one that meets your requirements.

- **Add date/time suffix**
File name: imageYYMMDD_HHNNSS_XX.jpg
Y: Year, M: Month, D: Day
H: Hour, N: Minute, S: Second
X: Sequence Number
- **Add sequence number suffix (no maximum value)**
File name: imageXXXXXXXX.jpg
X: Sequence Number
- **Add sequence number suffix (limited value)**
File Name: imageXX.jpg
X: Sequence Number

The file name suffix will end at the value entered in this box. For example, if the setting is up to "10," the file name will start from 00, end at 10, and then start all over again.

- **Overwrite** – The original image on the FTP site will be overwritten by the new uploaded file with a static filename.

Storage Management

The CM-722 has an integrated microSD™ card that can be used to record video or images. The card slot is compatible with a microSD™ card up to 32GB.

The screenshot shows the 'OpenEye' web interface with the 'System' tab selected. The left sidebar contains a menu with items: System, Security, Network, DDNS, Mail, FTP, Motion detection, Storage management (highlighted), Recording, File location, View log file, View user information, View parameters, Factory default, Software version, Software upgrade, and Maintenance. The main content area is titled 'Storage Management' and contains three sections: 'Device information' showing 'Device type: SD card', 'Free space: 0 KB', 'Total size: 0 KB', and 'Status: No'; 'Device setting' with a 'Format device' button; and 'Disk cleanup setting' with an unchecked checkbox for 'Enable automatic disk cleanup', 'Remove recordings older than: 1 day(s)', and 'Remove oldest recordings when disk is: 85 % full'. Below these is a 'Recording list' table with columns 'FileName' and 'Size', which is currently empty. At the bottom of the table are 'Remove', 'Sort', and 'download' buttons.

Device Information – Displays the storage total size and free space information of the included microSD™ card.

Device Setting – Allows you to format the microSD card. (You will need to format the card when using it for the first time.)

Device Cleanup Setting – Use this feature to enable overwrite settings on the SD card. The camera can remove files from the card after they reach a certain age, or when the card is a certain percent full.

Recording List – Displays a list of files saved to the card. You can delete files from the card, or save them to your local PC.

Note If you are using Windows Vista or 7, you will need to change the Snapshot location. Windows UAC does not allow internet programs to write directly to C:\ for security reasons.

Recording

The recording schedule allows you to set up scheduled recording to the microSD™ card.

The screenshot shows the OpenEye web interface. The top navigation bar includes 'Home', 'System' (selected), 'Streaming', 'Camera', and 'Logout'. On the left, a sidebar menu lists various system settings: System, Security, Network, DDNS, Mail, FTP, Motion detection, Storage management, Recording (highlighted), File location, View log file, View user information, View parameters, Factory default, Software version, Software upgrade, and Maintenance. The main content area is titled 'Recording' and contains the 'Recording Schedule' section. It features three radio button options: 'Disable' (selected), 'Always', and 'Only during time frame'. Below the 'Only during time frame' option, there are checkboxes for each day of the week: Sun, Mon, Tue, Wed, Thu, Fri, and Sat. Further down, there are input fields for 'Start time' (set to 00:00) and 'Duration' (set to 00:00). A 'Save' button is located at the bottom of the configuration area.

Recording Schedule – The camera can be set up to record continuously until the card is full (or overwrite old data, see the Storage Management section). The camera can also be set up to record only during a scheduled time. Select the days that you would like to record, then input the recording start time and the recording duration.

Activating microSD/SDHC Card Recording – Two types of schedule modes are offered: **Always** and **Time Frame**. You can set up the time frame to fit the recording schedule or choose **Always** to activate the microSD/SDHC card to record all the time.

Terminate microSD/SDHC Card Recording – Select **Disable** to terminate the recording function.

Snapshot

The camera supports a JPEG snapshot function. You can specify a storage location for the snapshot images. The default location is: C:\.

Note If you are using Windows Vista or 7, you will need to change the Snapshot location. Windows UAC does not allow internet programs to write directly to C:\ for security reasons.

Note Make sure the selected file path contains valid characters such as letters and numbers.

The screenshot displays the OpenEye web interface. The top navigation bar includes links for Home, System (selected), Streaming, Camera, and Logout. A left sidebar lists various system settings: System, Security, Network, DDNS, Mail, FTP, Application, Motion detection, Storage management, Recording, File location (highlighted), Iris adjustment, View log file, View user information, View parameters, Factory default, Software version, Software upgrade, and Maintenance. The main content area is titled 'File Location' and contains the instruction 'Set the destination of snapshot photos and recorded video files'. Below this, there is a label 'All files stored at:' followed by a text input field containing 'C:\' and a 'Select' button. A 'Save' button is positioned below the input field.

Information

The **Information** page contains the camera's System Log, User Information and Parameter List.

System Log

Click **System Log** to view the system log file. The content of the file provides useful information about configuration and connections.

The screenshot displays the OpenEye web interface. The top navigation bar includes links for Home, System (selected), Streaming, Camera, and Logout. On the left, a sidebar menu lists various system functions: System, Security, Network, DDNS, Mail, FTP, HTTP, Application, Motion detection, Network failure detection, Tampering, Storage management, Recording, Snapshot, Iris adjustment, Information, Software version, and Maintenance. The main content area is titled 'System log' and shows a scrollable list of log entries. Each entry includes a timestamp and a description of the event, such as network initialization, IP address assignment, and user login attempts. At the bottom of the page, there are three buttons: 'System Log' (highlighted), 'User Info', and 'Parameter List'.

System
System
Security
Network
DDNS
Mail
FTP
HTTP
Application
Motion detection
Network failure detection
Tampering
Storage management
Recording
Snapshot
Iris adjustment
Information
Software version
Maintenance

System log


```
[Wed Apr 18 21:30:00 2012] --Network interface initialized start
[Wed Apr 18 21:30:01 2012] --Network interface initialized end
[Wed Apr 18 21:30:01 2012] --Host IP = 10.253.253.69
[Wed Apr 18 21:30:01 2012] --Subnet Mask = 255.0.0.0
[Wed Apr 18 21:30:01 2012] --Gateway = 10.0.0.1
[Wed Apr 18 21:30:01 2012] --MAC address = 00:D0:89:09:28:71
[Tue Apr 24 00:12:17 2012] --Admin@::ffff:10.1.1.105 GET / HTTP/1.1
[Tue Apr 24 00:12:18 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/setlogout
[Tue Apr 24 00:12:18 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/ret.cgi HT
[Tue Apr 24 00:12:18 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/top.cgi H
[Tue Apr 24 00:12:18 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/center.cg
[Tue Apr 24 00:12:21 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/showdate
[Tue Apr 24 00:12:35 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/audio.cgi
[Tue Apr 24 00:16:54 2012] --Admin@::ffff:10.1.1.105 GET / HTTP/1.1
[Tue Apr 24 00:16:57 2012] --Admin@::ffff:10.1.1.105 GET / HTTP/1.1
[Tue Apr 24 00:16:58 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/setlogout
[Tue Apr 24 00:16:58 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/ret.cgi HT
[Tue Apr 24 00:16:58 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/top.cgi H
[Tue Apr 24 00:16:58 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/center.cg
[Tue Apr 24 00:17:01 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/showdate
[Tue Apr 24 00:17:12 2012] --Admin@::ffff:10.1.1.105 GET /cgi-bin/camset.c
[Tue Apr 24 16:31:02 2012] --Admin@::ffff:10.253.253.49 GET /cgi-bin/admin
[Tue Apr 24 23:50:55 2012] --Admin@::ffff:10.1.1.105 GET / HTTP/1.1
```

System Log User Info Parameter List

View User Information

The Administrator can view each user's login information and privileges on the **View User Information** page.

All users for the camera are listed under **User information**. The example below shows that the Admin password is 1234 and there is one user named User with the password 4321.



View User Privilege

Select a user account from the list and click **get user privacy** to view the permissions for the user account.

Parameter List

Click **Parameter List** to view the system parameter settings.

The screenshot displays the OpenEye web interface. The top navigation bar includes 'Home', 'System', 'Streaming', 'Camera', and 'Logout'. The left sidebar lists various system settings: System, Security, Network, DDNS, Mail, FTP, HTTP, Application, Motion detection, Network failure detection, Tampering, Storage management, Recording, Snapshot, Iris adjustment, Information, Software version, and Maintenance. The main content area is titled 'Parameter list' and shows the 'Mega Pixel Camera Initial Configuration File'. The configuration file content is as follows:

```
=====
[Camera setting]
=====
exposure mode = <auto>
min shutter speed = <5>
fixed shutter speed = <56>
white balance mode = <auto>
white balance rgain = <57>
white balance bgain = <54>
brightness value = <128>
sharpness value = <3>
contrast value = <64>
```

At the bottom of the main content area, there are three buttons: 'System Log', 'User Info', and 'Parameter List'.

Software Upgrade

OpenEye Home System Streaming Camera Logout

System

Version

The software version is **pc20120406NSA**

Follow these steps to update the camera firmware

Select the firmware update file

Browse...

Click Upgrade to begin the firmware update, the camera will restart during this process

Upgrade

Upgrading the Camera Viewer Software

Note Make sure the new firmware file is available before starting a software upgrade.

1. Click **Browse** and select the firmware file.

Note Do not change the file name, or the system will not be able to update to the new firmware.

2. Select the file type from the list under **Step 2**.
3. Click **Upgrade**. The system will check the upgrade file, and then upload the file. The upgrade status bar will display on the page. When it reaches 100%, the upgrade process is finished and the camera will return to the main page.


When the upgrade process is complete the viewer will return to the Home page. After updating it is important to make sure the camera viewer software is updated:

1. Close your browser.
2. Go to the **Windows Control Panel** and double-click **Add or Remove Programs**. Locate the **Camera Viewer** software on the **Currently installed programs** list, and click **Remove** to uninstall the previous software version.
3. Open the internet browser again and login to the IP camera. The system will automatically download the new version of the Camera Viewer software.

Maintenance

On the Maintenance page you can export the cameras current configuration, or import the configuration for a camera. Use the factory default page to reset the IP Camera to factory default settings if necessary.

Note Do not import configuration files from different models of cameras.



Set Default –To reset the IP camera to the factory default settings, including the default IP address, click Set Default. The system will restart after 30 seconds. If you cannot access the camera menu, you can return the camera to the factory default settings by holding down the reset button on the camera connection board for 30 seconds. See *Connections* for the button location.

Reboot – To restart the IP camera without changing the current camera settings, Click **Reboot**.

Export – You can save the system settings by exporting the configuration file (.bin) to a specified location for future use. Click **Export**, then **Save**, and specify the desired location.

Upload – To copy an existing configuration file to the IP camera, click **Browse**, select the desired configuration file, then click **Upload**.

Video and Audio Streaming Settings

On the **Streaming** tab, you can configure specific video resolution, video compression mode, video protocol and audio transmission mode.

Video Format

Select the desired video resolution for the camera on the Video Format page. The DVR will record video based on the resolution selected here.

The screenshot shows the 'OpenEye' web interface with the 'Streaming' tab selected. The left sidebar contains a menu with 'Video Format' highlighted. The main content area is titled 'Video Format' and contains the following settings:

- Video Resolution :** A dropdown menu set to 'H.264 + MJPEG'. Below it, 'H.264 format :' is set to '1920 x 1080 (15 fps)' and 'MJPEG format :' is set to '720 x 480 (30 fps)'. 'BNC support :' is set to 'Yes'. A 'Save' button is at the bottom of this section.
- Note :** Image attachment by FTP or E-mail will be available only while MJPEG streaming is selected.
- Text Overlay Settings :** Includes checkboxes for 'Include date' and 'Include time' (both checked), and a text input field for 'Include text string:'. A 'Save' button is below.
- Video Rotation:** A dropdown menu set to 'Normal video'. A 'Save' button is below.
- GOP Settings :** Four input fields for GOP Length: 'H.264-1 GOP Length : 60', 'H.264-2 GOP Length : 60', 'H.264-3 GOP Length : 30', and 'H.264-4 GOP Length : 30'. A 'Save' button is below.
- H.264 Profile :** Four dropdown menus for profiles: 'H.264-1 : Main profile', 'H.264-2 : Main profile', 'H.264-3 : Main profile', and 'H.264-4 : Main profile'. A 'Save' button is below.

Text Overlay Settings

Set up a text overlay for the transmitted video that can include the date, time, or custom text.

Video Rotate Type

You can change the orientation of the video output if necessary.

- **Normal** transmits the image as the camera sees it.
- **Flip** transmits the image upside down and mirrored.
- **Mirror** transmits a mirror image.
- **180 degree** transmits the image upside down.

GOP Settings

- Sets the Group of Pictures (GOP) length for the H.264 streams. Use this to increase bandwidth if necessary.

H.264 Profile

- Sets the H.264 Profile, or type of H.264 compression, for each H.264 stream. This may need to be changed only if you are using a 3rd party NVR that is not capable of decoding H.264 Main Profile.

Video Compression

You can select an MJPEG/H.264 compression mode on the video compression page appropriate for your application. You can also select to display compression information on the Home page.

OpenEye Home System **Streaming** Camera Logout

Video Format
Video Compression
Video OCX Protocol
Frame Rate Control
Video Mask
Audio

Video Compression

MJPEG Compression setting :
MJPEG Q factor : Mid
Save

H.264-1 Compression setting :
H264-1 bit rate : 4096 kbit/s
Save

H.264-2 Compression setting :
H264-2 bit rate : 1024 kbit/s
Save

H.264-3 Compression setting :
H264-3 bit rate : 1024 kbit/s
Save

H.264-4 Compression setting :
H264-4 bit rate : 1024 kbit/s
Save

Compression information setting :
☒ Display compression information in the home page
Save

CBR mode setting :
☐ enable H.264-1 CBR mode
☐ enable H.264-2 CBR mode
☐ enable H.264-3 CBR mode
☐ enable H.264-4 CBR mode
Save

MJPEG compression settings include:

- high compression, low bit rate, low quality
- middle compression, default
- low compression, high bit rate, high quality

H.264 compression settings include:

- 1024kbps, highest compression, lowest quality
- 2048kbps
- 4096kbps, middle compression, default
- 6144kbps
- 8192kbps, low compression, highest quality

CBR Mode Setting

- The Constant Bit Rate (CBR) mode could be the preferred bit rate mode if the bandwidth is limited. It is important to take account of image quality if choosing to use CBR mode

Video OCX Protocol

On the Video OCX protocol page, you can select different protocols for streaming media over the network. In the case of multicast networking, you can select the Multicast mode.

Video OCX protocol setting options include:

- RTP over UDP
- RTP over RTSP(TCP)
- RTSP over HTTP
- MJPEG over HTTP

Select a mode according to your data delivery requirements. If you are transmitting over the internet using a router and port forwarding, you need to use RTP over RTSP (UDP). You also need to forward the RTSP port to the camera (see the network setup page to find the RTSP port).

Multicast Mode

1. Enter all required data, including multicast IP address, H.264 video port, MJPEG video port, audio port and TTL into each box.
2. Click **Save** to confirm the setting.

Frame Rate Control

Setting the camera to transmit fewer frames can save bandwidth.

The screenshot shows the OpenEye web interface with the 'Streaming' tab selected. On the left is a sidebar menu with options: Video Format, Video Compression, Video OCX Protocol, Frame Rate Control (highlighted), Video Mask, and Audio. The main content area is titled 'Frame Rate Control' and contains five settings sections, each with a 'Save' button:


- MJPEG Frame Rate Setting:** MJPEG frame rate : 30
- H264-1 Frame Rate Setting:** H264-1 frame rate : 15
- H264-2 Frame Rate Setting:** H264-2 frame rate : 30
- H264-3 Frame Rate Setting:** H264-3 frame rate : 30
- H264-4 Frame Rate Setting:** H264-4 frame rate : 30

Each of the MJPEG and H.264 streams can have a separate frame rate setting from 1 to 30 frames per second

Note When set to 1920 x 1080, the max frame rate decreases to 15 frames per second.

Video Mask

You can use the video mask page to define a privacy mask to keep users from viewing parts of the image.



The screenshot shows the OpenEye web interface. The top navigation bar includes links for Home, System, Streaming (which is active), Camera, and Logout. On the left, a sidebar menu lists Video Format, Video Compression, Video OCX Protocol, Frame Rate Control, and Video Mask (which is selected). The main content area is titled 'Mask' and contains two sections: 'Active Mask Function' and 'Mask Setting'. The 'Active Mask Function' section has two checkboxes: 'Enable to display Mask1' and 'Enable to display Mask2', both of which are currently unchecked. The 'Mask Setting' section includes a 'Mask color' dropdown menu set to 'black' and a 'Type' dropdown menu set to 'solid'. A 'save' button is located at the bottom of this section. To the right of the settings is a live video feed showing a room with blue tables and a sign that reads 'QUALITY SERVICE'.

You can add two privacy masks and choose a color to obscure the live view from users.

Active Mask Function

- **Add a Mask** – Check a video mask checkbox. Use the mouse to drag, drop, and adjust the mask size and placement.
- **Cancel a Mask** – Uncheck the checkbox for the desired mask.

Mask Setting

- **Mask Color** – Masks can be red, black, white, yellow, green, blue, cyan, and magenta.
- **Type** – Masks can be solid or transparent.

Audio

On the Audio page, the Administrator can select an audio transmission mode and audio bit rate.

OpenEye Home System **Streaming** Camera Logout

Video Format
Video Compression
Video OCX Protocol
Video Frame Skip
Video Mask
Audio

Audio

Transmission Mode:

- ☐ Full-duplex (Talk and listen simultaneously)
- ☐ Half-duplex (Talk or listen, not at the same time)
- ☐ Simplex (Talk only)
- ☐ Simplex (Listen only)
- ☒ Disable

Server Gain Setting:

Input gain:

Output gain:

Bit Rate:

Note Audio monitoring and recording laws vary from location to location. It is highly recommended that you consult your local, state and federal laws to verify that you are in compliance before implementing audio recording.

Transmission Mode

- **Full-duplex (Talk and Listen simultaneously)** – In Full-duplex mode, the local and remote sites can communicate with each other simultaneously, i.e. both sites can speak and be heard at the same time.
- **Half-duplex (Talk or Listen, not at the same time)** – In Half-duplex mode, the local/remote site can only talk or listen to the other site at a time.
- **Simplex (Talk only)** – In Talk only Simplex mode, the local/remote site can only talk to the other site
- **Simplex (Listen only)** – The local/remote site can only listen to the other site.
- **Disable** – Turn off the audio transmission function.

Server Gain Setting

Set the audio input/output gain levels for sound amplification. The audio gain values range from 1 to 6. Sound can be turned off if audio gain is set to **Mute**.

Bit Rate

Selectable audio transmission bit rate include:

16 kbps (G.726)

24 kbps (G.726)

32 kbps (G.726)


40 kbps (G.726)

uLAW (G.711)

ALAW (G.711).

Both uLAW and ALAW signify 64 kbps but in different compression formats. Higher bit rate will provide higher audio quality and require more bandwidth.

Camera



Exposure

The exposure is the amount of light received by the image sensor and is determined by the width of lens diaphragm opening (iris adjustment), the amount of exposure by the sensor (shutter speed) and other exposure parameters.

Full Auto Mode

- In Full Auto mode, the camera's Shutter Speed, IRIS and AGC (Auto Gain Control) control circuits work together automatically to set a consistent video output level. The maximum shutter speed is adjustable from 1/30 to 1 sec.

Auto Iris Mode

- In Auto Iris mode, shutter speed and AGC circuit will function automatically in order to achieve a consistent exposure.

Fixed Shutter Mode

- In Fixed Shutter mode, fixed shutter speed are user selected from the available list. The shutter speed range is from 1/10000 to 1 sec. with 19 options. You can select suitable shutter speed according to the environmental illumination.

White Balance

A camera needs to find reference color temperature, which is a way of measuring the quality of a light source, for calculating all the other colors. The unit for measuring this ratio is in Kelvin (K). Users can select one of the White Balance Control modes according to the operating environment. The following table shows the color temperature of some light sources for reference.

Light Source	Color Temperature in K
Cloudy Sky	6,000 to 8,000
Noon Sun and Clear Sky	6,500
Household Lighting	2,500 to 3,000
75-watt Bulb	2,820
Candle Flame	1,200 to 1,500

Auto Mode

- In Auto mode, white balance works within its color temperature range and calculates the best-fit white balance.

Auto Tracking White Balance (ATWB) Mode

- In ATWB mode, the white balance will be automatically adjusted while the color temperature is changing.

Manual Mode

- In Manual mode, you can change the White Balance value manually, adjusting the R gain and B gain.

Backlight Setting

Backlight compensation prevents the center object from being too dark in surroundings where excessive light is behind the object.

Brightness

Adjust the image's brightness on the camera. The Backlight value is adjustable from -12 (dim) ~ +13 (brightest).

Sharpness

Increasing the sharpness level can make the image looked sharper; it especially enhances an object's edge. The value of sharpness is adjustable from +1 ~ +15 (sharpest) besides to default value.

Contrast

Correct the contrast of the entire image by adjusting the Contrast level, ranging from -6 ~ +19.

Saturation

Adjust the saturation of color components in an image through the Saturation function, which is adjustable from -6 ~ +19.

Digital Zoom

Zoom in to the center of the image.

IR Function

Adjust the IR cut filter settings for Day/Night functionality. When set to Auto the camera will analyze the video signal and choose when to switch from Day mode to night mode. When set to On the camera will always be set to night mode, and when set to Off the camera will always be set to day mode.

When set to Light Sensor the camera will only use the light sensor on the IR LED Array to determine when to switch to night mode, when set to Light On the camera will always have the IR LEDs turned on and when set to Light Off, the camera will always have the IR LEDs off, even when in night mode.

When set to Smart mode, the camera automatically stays in night mode if the IR illuminators remain on, even if the camera determines that it should switch to day mode.

TV System

Select the video format that matches the present video system.

Logout

Click the **Logout** tab to change users.

SPECIFICATIONS

CAMERA SPECIFICATIONS

Model	CM-722I	CM-722AI	CM-722VF
Image Sensor	1/2.7" Progressive CMOS		
Imaging DSP	Ambarella A5S		
IP Rating	IP66		
Type / Format	H.264 / MJPEG		
Wide Dynamic Range	Digital WDR		
Minimum Illumination	0.2 LUX (Color) / 0.02 LUX (B&W) / 0 LUX (IR LED)		
Day / Night	Yes (True Day / Night) + IR LED		
Resolution	15IPS @ 1920 x 1080 (2MP), 30 IPS @ 1280 x 1024 (1.3MP), 30 IPS @ 720p [1280 x 720 / 1MP), 30 IPS @ D1 [720 x 480], 30 IPS @ CIF (352 x 240]		
Service Monitor Jack	Yes (BNC)		
S/N Ratio	>50dB		
Focal Length	4mm fixed	3 ~ 9 mm motorized	3 ~ 9 mm varifocal
Iris Control	F1.5	F1.2	F1.2
Synchronization	—		
Video Output	1.0 Vp-p / 75Ω, BNC		
White Balance	Manual / AWB / ATW		
Auto White Balance Range	2700 K – 7800 K		
Backlight Compensation	On/Off		
Auto Gain Control	Auto/Manual adjustable through web		
Operating Temperature	-40°F ~ 122°F (-40°C ~ 50°C)		
Heater	Yes		
Power Consumption	5W + 3W (IR LED) + 12W (Heater) = 20W	5W + 3W (IR LED) + 12W (Heater) + 4W (Lens) = 24W	5W + 3W (IR LED) + 12W (Heater) = 20W
Rated Amperage	0.84A (24vAC)	1A (24vAC)	0.84A (24vAC)
Input Voltage	12vDC / 24vAC / PoE		
Weight	2.3 lbs (1 kg)		
Dimensions	L: 10.5" (266.7 mm) W: 2.375" (60.325 mm) H: 3.5" (88.9 mm)		
Housing / Dome Cover	White / Clear		

IR SPECIFICATIONS

Model	CM-722I	CM-722AI	CM-722VF
IR LEDs	23 IR LEDs (850nm)		
IR Range	Up to 50 ft (15 m)		

IP SPECIFICATIONS

Model	CM-722I	CM-722AI	CM-722VF
Video Compression	H.264 / MJPEG		
Dual Streaming	H.264 ONLY, MJPEG ONLY, H.264 + H.264, H.264 + MJPEG, H.264 + H.264 + H.264, H.264 + H.264 + MJPEG, H.264 + H.264 + H.264 + H.264, H.264 + H.264 + H.264 + MJPEG		
Audio In	1		
Audio Out	1		
Alarm In	1		
Alarm Out	1		
User Account	20		

APPENDIX A

SET UP INTERNET SECURITY

If the installation of ActiveX Control is blocked, you will need to either set the Internet Security Level to the default setting, or change the ActiveX controls and plug-ins setting.

Setting Internet Security Level to Default

1. Open Internet Explorer.
2. Click the **Tools** tab in the menu bar.
3. Click Internet Options.
4. In the **Security** tab, select the appropriate **Internet Zone**.
5. Click Default Level.
6. Click **OK**.
7. Close the browser window. You will need to open a new window in order to access the IP camera.

Adjusting ActiveX Controls and Plug-ins

1. Open Internet Explorer.
2. Click the **Tools** tab in the menu bar.
3. Click Internet Options.
4. Click **Custom Level**. The **Security Settings** window will pop up.
5. Under **ActiveX Controls and Plug Ins**, set all items to **Enable** or **Prompt**. Items may vary according to your version of Internet Explorer.

ActiveX controls and plug-ins settings:

- Allow previously unused ActiveX controls to run without prompt.
 - Allow Scriptlets.
 - Automatic prompting for ActiveX controls.
 - Binary and script behaviors.
 - Display video and animation on a web page that does not use external media player.
 - Download signed ActiveX controls.
 - Download unsigned ActiveX controls.
 - Initialize and script ActiveX controls not marked as safe for scripting.
 - Run ActiveX controls and plug-ins.
 - Script ActiveX controls marked safe for scripting.
6. Click **OK** to accept the settings and close the Security Settings window.
 7. Click **OK** to close the Internet Options screen.
 8. Close the browser window. You will need to open a new window in order to access the IP camera.

www.openeye.net

1-888-542-1103

© 2013 OpenEye

All rights reserved. No part of this publication may be reproduced by any means without written permission from OpenEye. The information in this publication is believed to be accurate in all respects. However, OpenEye cannot assume responsibility for any consequences resulting from the use thereof. The information contained herein is subject to change without notice. Revisions or new editions to this publication may be issued to incorporate such changes.